Page: 1 (1)

Ryhmä: 291

LM-82P MEAT MINCER

Code	Item name
LM82P015	LM-82P FOOT
LM82P024	LM-82P CABLE GLAND
LM82P025	LM-82P CABLE
LM82P060	LM-82P ENTRY NUT
LM82P066	LM-82P GASKET AS 25X47X7
LM82P068/1	LM-82P SHAFT
LM82P069	LM-82P KEY
LM82P071/1	LM-82P SPACER
LM82P082/1	LM-82P END SHIELD
LM82P085/1	LM-82P MOTOR 1,5kw
LM82P086	LM-82P FOOT
LM82P087	LM-82P CONTACTOR
	DILM 9-10
LM82P088	LM-82P THERMAL OVERLOAD RELAY
	ZB12-4
LM82P089	LM-82P TERMINAL BLOCK
LM82P090	LM-82P START BUTTON
LM82P091	LM-82P STOP BUTTON
LM82P092	LM-82P EMERGENCY STOP BUTTON
LM82P093	LM-82P RAIL
LM82P094	LM-82P PLUG
LM82P095	LM-82P NUT M12
LM82P096	LM-82P SCREW M12
LM82P097	LM-82P FRONT PLATE
LM82P098	LM-82P MEAT TRAY
LM82P099/1	LM-82P DISTANCE RING 12MM
LM82P099/2	LM-82P DISTANCE RING 28MM
LM82P100	LM-82P HOLEPLATE 3MM
LM82P101	LM-82P KNIFE
LM82P102	LM-82P HOLEPLATE 13MM
LM82P103	LM-82P PRECUTTER
LM82P104	LM-82P STUD
LM82P105	LM-82P KEY
LM82P106	LM-82P GRINDING HOUSE
LM82P107	LM-82P FRAME
LM82P110	LM-82P BUSHING
LM82P112	LM-82P FEEDING HAMMER
LM82P115	LM-82P WRENCH 18MM
LM82P116	LM-82P CLEANING BRUSH
LM82P117	LM-82P FEED SCREW (INCL.PART 104)
LM82P151	LM-82P GEAR BOX (COMPLETE SET)
LM82P202	LM-82 KEY
LIVIOZI ZUZ	LIVI-02 NE I

Items 40





