

Ref.	Product name	Code
1	ON/OFF SWITCH _	IB5800100
3	SWITCH FRAME	IB4000135
4	GASKET FOR MILKSHAKER	IB4100100
8	POTENTIOMETER	IB5940011
08A	PC BOARD	IB5940000
08B	PC BOARD VV	IB5940005
08C	PC BOARD VV 110/60 W/O FILTER	IB5940006
08D	BOARD VV220/60 W/O FILTER	IB5940002
10-1	ANODIZED ARM	IB1480110
12-2	ANODIZED BASE	IB1260120
12-3	ANODIZED BASE FOR	IB1080130
12-4	BOTTOM ENCLOSURE PANEL	IB4000000
12-6	PIASTRINA SCHEDA FILTRO	IB4000001
12-1	WALL SUPPORT	IB2280110
15	FILTER 03SS4 2012	IB5970801
16	FOOT FOR MILKSHAKER	IB4306400
17	POWER CORD + STRAIN RELIEF	IB5503001C
21A	ALUM.CUP HOLDER CE	IB9866020
21B	ALUM.CUP HOLDER NON CE	IB9866021
22	CUP HOLDER SUPPORT	IB4000131
23A	MOTOR ASSEMBLY+AGITATOR_ 120W	IB9865203
24	AGITATOR ALUMINUM END HEXAGON	IB2100110
25	S/S 416 WHISK	IB2200100
26	WHISK SPACER	IB2100100
27	CUP HOLDER MICROSWITCH	IB5820101
30B	MOTOR SUPPORT_WHITE	IB4060100
30A	CHROME MOTOR SUPPORT	IB4080100
30C	MOTOR HOLDER BLACK _	IB4070100
30D	MOTOR SUPPORT_RED	IB4030100
31	UPPER GASKET	IB4100110
32	SPEED VARIATOR KNOB	IB4200100
36A	CHROME MOTOR COVER	IB4080110
36C	MOTOR COVER BLACK _	IB4050110
36D	MOTOR COVER_RED	IB4030110
36B	MOTOR COVER_RED	IB4030110
38B	COFFEE APPLICATION	IB4000200
38A	AGITATOR INOX - MILK SHAKER	IB2200300
40	TERMINAL BOARD FOR SLICER	19410822